

# QuadGuard®M10 24"

**Product Description Assembly Manual** 









## QuadGuard® M10 610mm 24"

The QuadGuard® M10 has been tested pursuant to American Association of State Highway and Transportation Officials ("AASHTO") Manual for Assessing Safety Hardware ("MASH") specifications. The QuadGuard® M10 has been deemed eligible for federal-aid reimbursement on the National Highway System by the Federal Highway Administration ("FHWA").

## Product Description Assembly Manual



15601 Dallas Parkway Suite 525 Addison, Texas 75001



Warning: The distributors, owners, contractors, lessors, and lessees are RESPONSIBLE for the assembly, maintenance, and repair of the QuadGuard® M10. Failure to fulfill these RESPONSIBILITIES could result in serious injury or death.



**Important:** These instructions are for standard assembly specified by the appropriate highway authority. In the event the specified system assembly, maintenance, or repair would require a deviation from standard assembly parameters, contact a Ingal Civil Products representative. This system has been deemed eligible by the FHWA for use on the national highway system under strict criteria utilized by that agency.

This manual must be available to the worker overseeing and/or assembling the product at all times. For additional copies, contact Ingal Civil Products on 1300 446 425

The information contained in this manual supersede all previous versions. The instructions, illustrations, and specifications are based on the latest QuadGuard® M10 information available to Trinity Highway at publication. We reserve the right to make changes at any time. Please visit <a href="mailto:ingalcivil.com.au/products/road-safety-barriers/crash-cushions/quadguard-m10-mash">ingalcivil.com.au/products/road-safety-barriers/crash-cushions/quadguard-m10-mash</a> to confirm the latest revision.

## Table of Contents

Cust L er Ser Lee C Lacts3
□□ □ rta t □ tr □ duct □ r □ N tes □ □ □ □ □ □ 1 □ 1 □ 1 □ 1 □ 1 □ 1 □ 1
$Sa@t \square S \square \square \square s \square \square$
Salet Rules Ir Isse III IIII
$ L \hbox{$\sqsubseteq$} \ \text{$tat} \hbox{$\sqsubseteq$} \ \text{$a\_d} \ War \hbox{$\sqsubseteq$} \ \text{$s} \ \hbox{$\sqsubseteq$} \ \text{$\vdots} \$
$S \_ ste \_ \_ \_ er \_ e \_ \_ \_ \_ \\$
⊞s ect Sh ⊞
S ste C C C C C C
Deter□ □e Tra□st□□ T□ e □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
$Rec  \square  \square  e  \square ded  T  \square  Is  \square  \square  \square  \square  \square  \square  \square  \square  \square  $
Site recaration Foundation in the second sec
F_u_datch_r15
Truitu Huhuau oorooed odhesue oochoruo Sosteo uuuuuuuuuuuuuuuuuuuuuuuuuuuuuuuuuuuu
□ertīcal □□ch□rs □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
□ ch r □sse □ □ Caut □ c
H_rtalch_rs18
S ste sse s = sse = 1 = 1 = 1 = 1 = 1 = 1 = 1 = 1 = 1 =
$ \  \  \  \  \  \  \  \  \  \  \  \  \ $
Ma te a ce a d Re a r
IIIs Dect IIID Fre Due Do Discontinui IIII IIII IIII IIII IIII IIII IIII
□sual Dr⊞e □□ □s □ect □□ □ □□s □ect □□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
Wal III III III III III III III III III I
□ st □ cact □ struct □ s □ union
$ \   \Box arts   \Box r der \\  \  \Box \   \Box r \\  \  \Box cedure   \Box \   Dra \\  \  \Box \   \Box s \\  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \\  \  \Box \   \Box \\  \  \Box \   \Box \\  \  \Box \  \  \Box \   \Box \\  \  \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \Box \  \  \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \   \Box \   \Box \\  \  \Box \   \Box \   \Box \   \Box \   \Box \\  \  \Box \  \  \Box \   \Box \   \Box \   \Box \\  \  \  \Box \  \  \Box \   \Box \   \Box \\  \  \  \Box \  \  \Box \   \Box \   \Box \\  \  \  \Box \  \  \Box \  \  \Box \   \Box \   \Box \\  \  \  \Box \  \  \Box \  \  \Box \  \  \   \Box \  \  \  \  \  \  \  \  \  \  \  \  \$
□arts L͡stɪ͡s□□ □ua⊡tɪtes □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
□uad □uard □ M10 □ □Te □s □□□ Strut □ac □u□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
TS C□□crete □ad □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
TS Cocrete oad 800 Recar
Tess Strut caccuc
Mooratiosse of the annual content of the same of the s
Da hra □ □sse □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □
Sh □ □ti
Fe der alel ssella
Nose osseo do differencia de la companya del companya della compan
Sa@t□ Sha□e □arr@r Tra□st□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
Sole Sloe Tracston50
□ertical □arrier Tra⊡stiii□51
□ertical □arrier Tra□sitiii□□□xte□ded □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

## **Customer Service Contacts**

Ingal Civil Products is committed to the highest level of customer service. Feedback regarding the QuadGuard® M10, its assembly procedures, supporting documentation, and performance is always welcome. Additional information can be obtained from the contact information below:

#### **Ingal Civil Products**

Telephone	1300 446 425		
Contact Link	ingalcivil.com.au/contact-us		

## **Important Introductory Notes**

Proper assembly of the QuadGuard® M10 is critical to achieve tested performance that has been evaluated and deemed eligible by the FHWA per AASHTO MASH criteria. These instructions should be read and understood in their entirety before assembly. These instructions are for standard assemblies and used in conjunction with the assembly of the QuadGuard® M10 as specified by the applicable highway authority. If you need additional information, or have questions about the QuadGuard® M10, please contact the highway authority that has planned and specified this assembly and, if needed, contact Ingal Civil Products. This product must be assembled in the location specified by the appropriate project engineers. If there are deviations, alterations, or departures from the assembly protocol specified in this manual, the device may not perform as tested.



**Important: DO NOT** use any component part that has not been specifically specified herein for the QuadGuard® M10 during the assembly or repair of this system (p. 7 - 10 / 38 - 39).

,

A manufacturer's drawing package will be supplied by Ingal Civil Products upon request. Each system will be supplied with a specific drawing package unique to that system. Such drawings take precedence over information in this manual and shall be studied thoroughly by a qualified individual who is skilled in interpreting them before the start of any product assembly.

## **Safety Symbols**

This section describes the safety symbols that appear in this manual. Read the manual for complete safety and assembly information.

#### **Symbol**

#### <u>Meaning</u>



**Safety Alert Symbol:** Indicates Important, Caution, Warning, or Danger. Failure to read and follow the Important, Caution, Warning, or Danger indicators could result in serious injury or death to workers and/or bystanders.



**Warning:** Read safety instructions thoroughly and follow the assembly directions and suggested safe practices before assembling, maintaining, or repairing the QuadGuard® M10. It is the responsibility of the installer to follow the instructions contained in this manual. Failure to comply with these warnings could result in increased risk of serious injury of death in the event of a vehicle impact.



**Important:** Please keep up-to-date instructions for later use and reference by anyone involved in the assembly of the product.

## Safety Rules for Assembly

#### \* Important Safety Instructions \*

This manual must be kept in a location where it is readily available to persons who are skilled and experienced in the assembly, maintenance, or repair of the QuadGuard® M10. Additional copies of this manual are available from Ingal Civil Products on 1300 446 425 or by visiting <a href="mailto:ingalcivil.com.au/products/road-safety-barriers/crash-cushions/quadguard-m10-mash">ingalcivil.com.au/products/road-safety-barriers/crash-cushions/quadguard-m10-mash</a>. Please contact Ingal Civil Products if you have any questions concerning the information in this manual or about the QuadGuard® M10.

It is the responsibility of the installer to use appropriate safety precautions when operating power equipment, mixing chemicals, and when moving heavy equipment or QuadGuard® M10 components. Safety articles including but not necessarily limited to work gloves, eye protection, safety-toe shoes, and back protection should be used.



**Warning:** It is the responsibility of the installer to use all safety measures incorporating appropriate traffic control devices specified by the highway authority. These measures must be used to protect all personnel while at the assembly, maintenance, or repair site.



**Warning:** Failure to comply with these warnings could result in increased risk of serious injury or death in the event of a vehicle impact with a system that has not been accepted by the FHWA.



**Warning:** Use only Trinity Highway parts on the QuadGuard® M10 for assembly, maintenance, or repair. The use of component parts not specified herein is **strictly prohibited**. The QuadGuard® M10 assembled with Trinity Highway parts has been tested, approved, and accepted for use by the FHWA. A QuadGuard® M10 using parts other than those specified herein has not been tested, approved, or accepted for use by the FHWA. Failure to follow this warning could result in increased risk of serious injury or death in the event of a vehicle impact.

## **Limitations and Warnings**

□ursua t □ M□SH □Rec □□ □ e □ded □r □cedures □r the Sa □et □ □er □r □ a □ce □□H□h□a□ Sa □et □ Features □□ Tr □t□ H□h□a□ c □tracts □ □th FHW□ a □r □ □ed test □□ □ a □tt□ □t□ t□ a □et □ a □et □ su □□ □t□ □t□ □t□ □t□ □t□ □t□ □t□ □t□ □t□
The QuadGuard® M10 system has been deemed eligible by FHWA as meeting the requirements and guidelines of MASH. These tests evaluate product performance defined by AASHTO involving lightweight cars (approx. 1100 kg [2420 lb.]) and full size pickup trucks (approx. 2270 kg [5000 lb.]). A product can be certified for multiple Test Levels. The QuadGuard® M10 is certified to the Test Level(s) as shown below:
Test Level 3: 100 kph Test Level 2: 70 kph
These AASHTO directed tests are not intended to represent the performance of systems when impacted by every vehicle type or every impact condition existing on the roadway. This system is tested only to the test matrix criteria of MASH as approved by FHWA.
Trillto Hillhola excressio disclatos and narranto or liantito for more or danane to cersors or crocerto resultino find and to cactocolistico or harmold contact of the or ducts of the reducts near on harmold ards or not the or ducts nere assended to consultation of the Trillto Hillhola or not hill carties.
The _uad_uard_ M10 s _te_ded to _e asseled_del_eated_a_d _a_ta_ed _th_ sec_c state a_d _ederal _udel_est s
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐
Warning: D = Ct asse = Ce = a the cuad card the cuad card M10 uctil Cu hace read this cacual thoroughleadd co deteloucherstacd it



**Warning:** Desure that all Dader Ward Caut Daded Data t state ets the this dad are coldeted Diloded Fature to Dilo this dard cold result ser us Duro r death the elect Da collision

## **System Overview**

The <code>uaduard</code> M10 is a reidirect contation crash cush or reads de reatures of 2001110 or reater of odth of the use of a or oded transitions of consists of elementars or ode cartridges surrounded on a rade of contact of a delso



Important: Trinity Highway makes no recommendation whether use or reuse of any part of the system is appropriate or acceptable following an impact. It is the sole responsibility of the project engineer to make that determination. It is critical that you inspect this product after assembly is complete to make certain that the instructions provided in this manual have been strictly followed.

The <code>uaduard</code> M10 utilles to toes ocartridoes on a staced coolinate that are desocated and tested to address cehicles as defined <code>mash</code> or oth lighter cars and header high center of the center of the cehicles.

#### **Impact Performance**

The three 3 a a uad uard M10 has successull assed the relure ets stillated MSH of the lith the lith car ad cultrucs at speeds aut to 0 of home a heat redirect a cles u to 25 decrees





Warning: It is the sile results with on the project element of element that the local units with the local standards with the local standards.

## **Inspect Shipping**

Chec the rece to carts a at the shind list succeed to the seste course de at the square with the seste course de at the square with the seste course de at the square decorate decorate



Important: The Ma\_uacturers Dra\_ aca e su\_led of the uad uard M10 out e used of these struct sor roler assect acd should take recedence of these eleral struct so




Warning: D□N□T □ □d □ the □ uad □ uard □ M10 □ a □ □ □a □ □

## **System Components**


elo s a list ossiste co occets that oa e used our carticular ouadouard M10 commuration erio carts delivered and siste details of the object of many siste of the occupant of t


Note: C = = ts are = t sh = t scale

















## **Determine Transition Type**

Note: \_\_\_\_r\_er Tra\_st\_\_\_\_a\_el \_r Side \_a\_el \_ ust \_e used \_\_\_each side \_\_the \_ac\_u\_\_\_ Side \_a\_el \_s used \_\_the \_ac\_u\_\_\_ Side \_a\_el \_s used \_\_the \_ac\_u\_\_\_ Side \_a\_el \_s used \_\_the c\_rrect \_a\_el\_s\_t use \_\_tt \_a\_e \_a\_t de\_ed \_\_the \_ac\_u\_\_ Side \_a\_el \_s used \_\_the \_ac\_u\_\_ Side \_a\_el \_s used \_\_the \_ac\_u\_\_ Side \_a\_el \_s used \_\_the \_ac\_u\_\_ Side \_ac\_u\_\_\_ Side \_ac\_u\_\_ Side \_ac\_u\_\_ Side \_ac\_u\_\_ Side \_ac\_u\_\_ Side \_ac\_u\_\_\_ Side \_ac\_u\_\_ Side \_ac\_u\_\_ Side \_ac\_u\_\_\_ Side \_ac\_u\_\_ Side \_ac\_u\_\_\_ Side \_ac\_u\_\_\_ Side \_ac\_u\_\_\_ Side \_ac\_u\_\_\_ Side \_ac\_u\_\_\_





## **Recommended Tools**

#### **Documentation**

- Ma□u□acturer□s □sse□□□Ma□ual
- Ma□u□acturer□s Dra□□□□□□ac□a□e

#### **Personal Protective equipment**

- □ □ e □ r □ tect □ □ □
- □I□□es
- □r tect tect Cl th III
- Rellect le lest

#### **Cutting equipment**

- R □ tar □ Ha □ □ er Dr □
- Re ar cutt at
- C crete drill its 22 in (Double-Fluted)
- □r der Hac a □r T rch tt al



Important: Trillt: Hillhaarecaa eads us adouble-fluted drillats tache eath u teaste streath aheaalanaaaraed adhes each rillas steamats.

#### Hammers

- Sled eha ⊓er
- Sta □dard ha □ □ er

#### **Wrenches**

- Hea □ dut □ 1 12 □ dr □ e □ □ act □ re □ ch
- 1 1/2" dr 1 1/
- 1 □2" dr □e Ratchet a □d attach □ e □ts
- 1 12" dr □ e □ rea □ er □ ar □ 2 □ □ □ □ □
- 1 12" dr □ e T □ r □ ue □ re □ ch □ 200 t □ □
- Hex □e□ □□lle□□□re□ch□ 318□



Important: Trinity Highway makes no recommendation whether use or reuse of any part of the system is appropriate or acceptable following an impact. It is the sole responsibility of the project engineer to make that determination. It is critical that you inspect this product after assembly is complete to make certain that the instructions provided in this manual have been strictly followed.

#### **Miscellaneous**

- Tra III c c tr l e u l e t
- Lifting and noting equipped in lifting dense is preferred although a minimized be used in Minimized 5.000 local action required in
- Din Cooressor 1100 os on the up to a color of the coorest of the coores of the coore
- Loop or car
- Dr 🖽 🗆 300 🗆 🗆
- Ce ☐ter ☐u ☐ch
- Ta □e □ easure □5 □ 125 □
- Chalkline
- Concrete marking pencil
- Steel bristled tube brush for cleaning 22mm drilled boreholes
- Rags, water, and solvent for touch-up

Note: The provided list of tools is a general recommendation and should not be considered an extensive list. Depending on specific site conditions and the complexity of the assembly, the required tools may vary. Decisions as to what tools are needed to perform the job are entirely the responsibility of the selected contractor performing the assembly of the system at the specified assembly site.

## **Site Preparation/Foundation**

□ uad □ uard □ M10 □ □ r □ er □ a □ er ta □ □ cat □ s □ s □ h □ ld □ e asse □ ed □ a □ ex st □ □ r □ r □ eshl □ □ aced a □ d cured c □ crete □ ase □ 28 M □ a □ 000 □ s □ □ □ u □ u □ □ L □ cat □ □ a □ d □ r □ etat □ □ □ the c □ crete □ ase a □ d atte □ uat □ r □ ust c □ □ □ □ th □ r □ ect □ a □ s □ r as □ ther □ se deter □ □ ed □ □ the l □ cal h □ h □ a □ auth □ r □ ext □ a □ s □ r as □ ther □ se deter □ □ ed □ □ the l □ cal h □ h □ a □ auth □ r □ ext □ s □ the l □ cal h □ h □ a □ auth □ r □ ext □ s □ the l □ cal h □ h □ a □ auth □ r □ ext □ s □ the l □ cal h □ h □ a □ auth □ r □ ext □ s □ the l □ cal h □ h □ a □ a □ ex st □ l □ cat □ l □ cat □ l □ cat □ l □ the l □ cat □ l □ the l □ cat □ cat □ l □ the l □ cat □ l □ the l □ cat □ cat □ l □ cat □ cat □ l □ cat □ cat □ l □ cat □ l □ cat □ c

Rec c eded d es ad refire et sectetis in ec correte indications are conded in Trinita High a concrete indication dra indications succeed at the siste of the indication surface shall have a limit of the siste of the indication of the siste of the indication surface shall have a limit of the siste of the indication of the siste of the indication surface shall have a limit of the siste of the indication surface shall have a limit of the siste of the indication surface shall have a limit of the siste of the indication surface shall have a limit of the siste of the indication surface shall have a limit of the siste of the sist



Warning: It is the results with the staller the staller the sure of the orange of the state of t



Caution: □ccurate □ace □ e t □ all steel re □ar s critical t □ a □ d □ ter e re □ th the c □ crete a □ ch □ r □ □ ts □




Figure 8
Cross-Slope



Warning: Location on the local or relation to locate of all allect the location of the attenuation of the local or relation to location of the attenuation of the local or relation to location of the local or relation of the local or re



Important: Sstessinuted as halt sust se respaced and susted seems such as halt sust se respaced and susted seems halt susted as halt such seems are such as are dated respace the datased at chars such as halt susted as halt susted so sites and respected elements and structures are structures and structures and structures and structures are structures and structures are structures and structures and structures are structures

## Foundation/Anchoring



**Important:** It is the res□□s□□the I□cal D□T t□e□sure that this asse□□c□□□t□s t□the □□SHT□ R□adside Des□□□□uīde□



**Warning:** It is the resource with the staller to ensure that the assection of the staller to ensure that the same with assection authorities standards.

#### **Asphalt Installations**

S_ste_s _fth a Te_sStrut _ac_u _ a _ ce terar to _stalled _ c_struct coes _ c
as halt see les cales as Asphalt Concrete ("A.C.") aust crade a a le un un concrete a les cales as les cales a
□ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □
("P.C.C.")□152 □ □ □□□□ a□er □□as□halt □□er 152 □ □ □□□□ a□er □□su□□ase□□r 200 □ □ 18□□ a□er
□□as□halt □ th □□ su □□ase□



Important: 0 0 0 0 0 18 threaded rods out the Trotto Hohoa a crosed adhes to call the used of the asphalt of the call the used of the asphalt of the call th

#### **Concrete Installations**

For concrete installations the quadquardq M10 should be installed and an existing or ireshlo
□aced a □d cured c □□crete □ase □□000 □s □28 M □a □□ □□□ u □ □□re □tat □□□ □□the c □□crete □ase
$\verb a   \verb d  the atte   \verb u  att    \verb u  ust c   \verb u    \verb d    \verb d  the   \verb c  r   \verb d  ect     \verb d  a   \verb s      ct     a   ct   ect     a   ct   ect   ect$

The <code>uaduard</code> M10 <code>a</code> <code>e</code> <code>stalled</code> <code>u</code> <code>a</code> <code>u</code> <code>u</code> the <code>ull</code> <code>u</code> <code>u</code> <code>datus</code> us <code>u</code> the scecifed <code>a</code> <code>ch</code> <code>ra</code> <code>e</code>

#### Foundation A: Reinforced Concrete Pad or Roadway

F⊡u⊡dat⊞⊟⊟	152 🗆 🗆 🕮 🕮 u 🗆 de 🗆 th 🗆 🗷 🗅
□□ch□ra□e□	□□□□□□ed adhes⊞e □th 180 □ □ □□□studs 1□0□ □ t5 1□2□□e□ □ed□ e□t

#### Foundation B: Asphalt over P.C.C.

F⊡u⊡dat⊞⊟⊟		3 u	as⊡halt c⊡⊏crete	□ C □ □ er		<b>3</b> □□□ u	
□□ch□ra□e□ L	.e□□th □	⊑a⊑ch⊑r re⊑u	red s ==0 = = 1	8⊡a⊡d e⊟ □	ed□e⊡t	□□□20 □ □	<b>1 1 2 3</b>

#### Foundation C: Asphalt over Subbase

F⊡u⊡dat⊞⊟⊟	152 🗆 🗆 📖 📖 u 🗆 🗅 C 🗆 Cer 152 🗆 🗎 📖 u 🗅 C 🗅 Cacted Su 🗀 ase 🖒 🖫
□□ch□ra□e□	□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

#### Foundation D: Asphalt Only

F⊡u⊡dat⊞⊟⊟	200 🗆 🗆 18 🕮 🗎 🕮 u 🗆 🗆 🖸 🗆
□□ch□ra□e□	□□r□ced adhes⊡e □fth □□0 □ □ 18□studs □20 □ □ □1□1□2□ce□ □ed□e□t

## **Trinity Highway Approved Adhesive Anchoring System**

□ TrⅢt□ HⅢh□a□ a□r□Ced adhesⅢe a□ch□rⅢ□ s□ste□ ाs re□ured t□ securel□ a□ch□r crash cushⅢ□s□□ach a□r□Ced adhesⅢe □t] c□□taⅢs adhesⅢe □studs□□uts a□d □ashers□□th □ert□cal a□d h□rⅢ□tal asse□ □les are □□ssⅢe usⅢ□ a□a□r□Ced adhesⅢe a□ch□rⅢ□ s□ste□ □

#### **Vertical Anchors**

Note: Read all Trinity Highway approved adhesive instructions before starting.

**1** □ Prepare the Concrete Foundation





Warning: It is the results with the staller to a table a sale or area clud to the use obstacdard or one saletoeumeet o one does saletoe to shoes a decelerated

#### 2) Drill Boreholes



Caution: It is the responsibility of the installer to consult Safe Work Australia, WorkSafe NZ, or state & territory authorities for debris removal from borehole(s) and use Trinity Highway approved adhesive to achieve optimum tensile strength. Do not use diamond drill bits for drilling boreholes.

		Anchori	ng Information		
Stud Size: Orientation Bit Size Minimum Depth Torque		Torque	Medium		
M20 x 180 □	□ertīcal	22 🗆 🗆 🗆 18 🗆	1⊡5 □ □	Ma⊒u⊡acturer S⊡ec	C□□crete
M20 x □□0 □ □	□ertīcal	22 🗆 🗆 🗆 🗷	□25 □ □	10 III	□s⊡halt



Important: When mounting on asphalt, initial torque shall be as shown above. Due to the properties of asphalt, anchors may loosen over time. For this reason Trinity Highway recommends anchoring to asphalt only at temporary locations. It is recommended to re-torque anchors in asphalt every six (6) months to the proper initial torque specified.

3)	Clean the Boreholes  I the cocrete dust room the corehole us combined combined a ressed a room the roughloursh to the a 22 combined a territory steel or steel or steel or ush and the combined a					
		othe Triiitii Hiiih aa aoroced cacuuo driiiiiio eouiiio e id crushiiio recuireo eot ooSteo 3o	It is auth⊡r⊞ed t⊡ re⊡ace			
4)		reh⊡e 100□ ໝll□				
_	<u> </u>	Caution: Fttl □□reh□e 100□ tull s□ tt s e□e□ □tth tt□ a□utacturers ttstructtt□s□	ne ⊡a⊡e⊡e⊡t sur⊡ace ⊡er			
5)	Add the V	Vashers and Nuts				
,		it □asher □□t□ the stud the□ thread a □ut □□ u□t∄the e⊡d ∄ush □fth the □ut เ#⊞ure 9⊞				
6)	Insert Stu	ds in Boreholes and Wait for Adhesive to Cure				
	□ush the □□reh□le□	stud d□□□ thr□u□h the □art t□ □e a□ch□red a□d □□t□	the			
_	<u> </u>	Caution: D	No. of Concession, Name of			
7)	Torque th	e Nuts	Figure 9			
		adhes⊞e has ໝll□cured⊡t⊡r⊡ue the ⊡ut t□the adhes⊞e rer⑤ rec□□ □ e⊡ded ⊡alues□	Vertical Application (Before Applied Torque)			
Ar	nchor As	sembly Cautions				
1)	Steel reba	ır				
	steel re  ste	ar s e⊡c⊡u⊑tered □hte drttl⊞□ a□ a⊡ch⊡r □⊡t □⊡reh⊡e□	a a d a a coe a cothe a d a a a a a a a a a a a a a a a a a			
		re ar drt at ar the <b>rebar only</b> ad the satch acat at the uder accrete udt the crater arehae de				
_	<u> </u>	Caution: Do out drill through recar ofthout instructation the project economicer.	□□□□ □er□ īss□□□ t□ d□ s□			
		□e□ □□reh□e d□□□ at a□ a□□e □ast the re□ar t□ the □r□ □ c□□ □etel□ □Ⅱ□□ □□th □□reh□es □ th a□ a□□r□□ed adhe				

#### **Horizontal Anchors**

The harder adhes to the sale as the certical attack.



Caution: F

□□reh□e 100□ □ull s□ t

□ s e □e□ □th the □ert □al c□□crete sur □ace □er □a□uacturer


□ s □struct□□s□

- 1) Follow the instructions supplied with your approved adhesive kit
- 2) Add the Washers and Nuts
  - □ut □asher a□d □ut □□ stud s□ the **nut is flush with end of stud**□
- 3) Insert each Stud with Washer and Nut into Borehole


□ush stud □th □asher a □d □ut □t□ □□reh □e□



**Important:** The stud should be dush ofth the too on the out of on the vertical and horizontal and catoos or or to to the out of the out of out of the out



**CORRECT** 



**INCORRECT** 

Figure 10
Horizontal Application
(Before Applied Torque)



**Caution:** Do out disturbor load the stud upto the accreted adhes to a derivation harded disturbor and the stud upto the accrete distribution and the students of the students

#### 4) Torque the nuts

□ ce the adhes e has cull□ cured troue cuts to the acrosed adhes e □ acutactur cured scentificat




Figure 11 Plan View




Figure 12 Elevation View 6 Bay TL-3





Figure 13 3 Bay TL-2

#### **How to Determine Left/Right**


To detero the left from right the order to carts stand to the siste of action the roads de costacle of our left is the siste of left and the right of the siste of action the roads de costacle of our left is the siste of action to the roads de costacle of our right of the siste of action the roads de costacle of our right of the siste of action the roads de costacle of our right of the siste of action the roads de costacle of our right of the siste of action the roads de costacle of our right of the siste of action the roads de costacle of our right of the siste of action the roads de costacle of the siste of action the roads de costacle of the siste of action the roads de costacle of the siste of action the roads de costacle of the siste of action the roads de costacle of the siste of action the roads de costacle of the siste of action the roads de costacle of the siste of the

#### **Counting the Number of Bays**

**Note:** There of all all as the order of the control of the state of the control of the state of the control of the state of the control of t



#### **Measuring the Width**






Figure 15 Width of Parallel system

## **System Assembly**



**Warning:** If the QuadGuard system has been supplied pre-assembled, it will have transport bolts with warning tags installed in the monorail. These monorail bolts are used to hold the system together while in transit and therefore are for transportation purposes only. They MUST be removed during installation of the QuadGuard system. It is solely the responsibility of the installer to ensure any transport bolts are completely removed. Failure to remove can affect the systems performance and may result in personal injury or death.





**Warning:** It is the responsibility of the installer to ensure the assembly procedure meets all appropriate Safe Work Australia, WorkSafe NZ, or state & territory authorities standards.

#### 1) Mark System Location

Locate the centerline of the system by measuring the proper offset from the fixed object. Refer to the Drawing Package supplied with the system. Place chalk line to mark the centerline of the system. Mark a construction line parallel to the center line and offset 165 mm [6.5"] to one side as shown in Figure 16. The edge of the Monorail will be positioned on this line.

**Note:** The concrete foundation must comply with the Manufacturer's Drawing Package supplied with the system.



**Warning:** Location of system with respect to the roadside obstacle is critical and dependent on the type of Transition Panel used. Please refer to the Drawing Package supplied with the system for details.



Figure 16 (Top view of concrete foundation)

#### 2) Anchor the Tension Strut Backup (Figure 17)

Locate Tells Strut Strut Strut and Moral of Sudation of the side of Moral of the construct of the side of Moral of the construct of the side of Moral of the side of the side



**Caution:** Der hile the laclud and Monratid ust be alchored to a studius and an orded adhestie to a studius.




Figure 17
Anchoring Tension Strut
Backup to Foundation

#### 3) Anchor the Monorail

#### **Monorail Placement for Tension Strut Backup (Figure 21)**

Locate Mooration outdation of side of Mooration the construction line and rear edge of actual out 100 or other and order of the construction line and rear edge

□re the M□□ra that the M□□ra that the M□□ra that the □ac □□□



**Warning:** In the moderation of the moderation o

the indicated and the cache of the cache of

#### 4) Attach Side Panels and/or Transition Panels to Backup Assembly

attach Trastillo da el or Side da el toside do acudosido 58 anatodat a od 58 anatodat de da el toside do acudos el da el

Note: Do out use a Side oalel oheoa Tracsitiii oalel is usedo

#### **Assembly Tip:**

Use drift pin to align the center hole of the Side Panel with the center hole of the Backup before inserting the Rail Bolts  $\!\Box$ 






Figure 18
Side Panel/Transition Panel Attachment










Figure 21
Backup and Monorail Location for Tension Strut Backup

ingalcivil.com.au 2□ Re□s□□□□□□12021

#### 5) Attach Monorail Guides

□ttach M□□□rati□udes t□ Da□hra□□ as □II□□s□

□sert 3□□x 2□□8 hex □It thr□u□h M□□□ratl□ude a□d Dā□hra□□ □th a sh□□ □laced
□et□ee□the□ a□d □rē□ted as sh□□□□□ F□□ure 22□Secure □th 3□□□□□□ asher a□d 3□□□
hex □ut tt□□cal □□laces□See the Dā□hra□□□sse□□□dra□□□su□□lēd □th the s□ste□□□

Re eat □r cess □r each D a hra □ □

#### 6) Attach Diaphragms

□rret a Dathra□□ s□that the root race □the Dathra□□ shale races t□□ard the Nose □the soste□ as sh□□□ □ Foure 23□



**Important:** Slīde □□e Dīa□hra□□ all the □a□t□ the □ac□u□t□e□sure the s□ste□ s a□e t□c□la□se □r□□erl□dur□□□ □□act□




Figure 22
Monorail Guide Attachment

Figure 23 Diaphragm Orientation




Figure 24
Diaphragm Spacing

#### 7) Attach Fender Panels

Note: D = It is the 58 ratiouts flar = Ith the 58 hex outs is all if flure 25 in




Figure 25
Rail Nuts are Oversize

**Note:** Start at the acusattach let ad rate Feder ales shows all stems 5 with each tapered end pointing toward the rear of the system (p. 27).

#### Step 1

□lace the Fe⊑der □a⊑el s□ that the ce⊑ter □□the sl⊡t □□the rear□ard Dख̄□hra□□ ।≌ l⊞ed
u□ □fth the a□□r□xⅢ ate ce□ter □□the sl□t Ⅲ the Fe□der □a□el□
□ttach Mushr□□□ Washer □sse□ □□ as sh□□□ □□ F□□ure 2□□Deta⑪2□a□a□d 2□□□D□ □□
t⊡r⊡ue taste⊑ers at thts t⊞le⊡Thts tSte⊡ 1⊡hel⊡s t⊡ tala⊡ce the Fe⊡der ⊡a⊡el⊡

#### Step 2

Slide the Felider lacel in ard until the holes in the Felider lacel line undit the holes in the in ard Dachran  $\square$ 

#### Step 3

**Note:** Wording the lacturessed de aid tilhted each lacture at a tille tolard the Nose of the sisted of

#### Step 4





Figure 26
Fender Panel Assembly

#### Step 5

□e sure Mushr□□□ Washer la s tat a at the Fe der □a el as sh□□□ □ Deta to 2 □□□ Sta □d □□□□ Mushr□□□ Washer □ ust □e seated c □□ □letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□□ tat □ letel □ thr □u □h sl to □□ tat □ letel □ thr □u □h sl to □□ tat □ letel □ thr □u □h sl to □□ tat □ letel □ thr □u □h sl to □□ tat □ letel □ thr □u □h sl to □□ tat □ tat □ letel □ thr □u □h sl to □□ tat □ tat □



Detail 26a Mushroom Washer Attachment Detail 26b Mushroom Washer Orientation



**Important:** Start □□□ □□□ the □ac □□□□attach a □d t □□hte □ each □a□ sect □□□ □□e at a t □□ e □

#### Step 6

Chec Da hra seac to esure 915 of 3 of et ee rear aces of consecut to Da hra sassing the edge of each assection of the ender of each assection of each

#### Step 7




Figure 27
Proper Diaphragm Spacing

#### 8) Attach End Cap

□ttach the □□d Ca□ t□ the □□d t□ the □□st M□□□ra□ se□□ e□t□as sh□□□ □el□□ a□d the M□□□ra□□sse□□□dra□□□□□




Figure 28
Monorail End Cap Attachment

#### 9) Attach Lower Cartridge Support Brackets




Figure 29
Lower Cartridge Support Bracket Assembly




Figure 30
Lower Cartridge Support Bracket Assembly
(Tension Strut Backup)

#### 10) Nose Assembly






Figure 31 NOSE ASSEMBLY (p. 47)

- □□□ □ttach □reasse□ □led N□se □sse□ □l□ t□ □r□□t D□a□hra□□ □□th 5⋅8X5 ra□□□□ts□□ar □ashers□3□□ sch 80X3□□□e□□ull□ut □rac□ets a□d 5⋅8 hex □uts□D□ □□t t□□hte□ at th□s t□□ e □Deta□s 31c□31d□31e□□
- Collider Note assection height so too growth Note is 815 to a collider collider and Twitten all six colliders and outs to the second state of the second se
- Do stall Tope 1 Cartridge surmo directional arror is counting to inout obsisted a
- □□ □sse□□e □uad□uard□ M Cartrod□e H□d D□□□ □rac□et □fth 3f8X1 hex □□ts□□ashers a□d □uts □F□ure 32□□









Figure 32 Hold Down Bracket Assembly

Note: Figure 33 shows proper placement of Cartridge Nose Support Bracket.



#### 11) Checking the System Assembly

this count rechec to ecsure that all lasteders are crossed to the determined the sisted lands and the country of the country o



Warning
□□t T⊡r⊡ue Re⊡ure□e⊑ts
□□ch□r Studs □ □□1 □
Crítīcal Cleara ⊑ces
□□ch□r Studs a□□□e □uts □ □□2□□F□□ure 20
Fe⊑der □a□el □a□ □20□ □ □□8□F□ure 3□




Figure 34
Fender Panel Gap

#### 12) Cartridge Placement

The tosurace of the Nose Cartrolle should be horizontal of cool determine assed to the assed to the action of the sisted of the



**Warning:** □lac □□□ the □r□□□ Cartro □e □□ the N□se □r □a□s□c□uld result □□ u□acce □ta□e crash □er□r□a□ce □er M□SH critera a□d cause ser□us □□ur□ □r death t□□ccu□a□ts a□d □r□r□sta□ders □□the e□e□t□□a□the □e□t□□a□the □e□t□□a□the□□act□



Important: The □uad □uard □ M10 s a s x □□□□a □ c □□□□urat □□□□

## **QuadGuard® M10 610mm [24"] Final Inspection Checklist**

Site L	Site Location:				
Date:	Date:				
Inspe	Inspector:				
Refe	r to the QuadGuard <sup>□</sup> M10 61mm [24]" manual and / or drawing package.				
	Tra still a el its ir the siset ill 11				
	Cleara ce como 5 como central rear Fecter carels cor slide caco como 1 como 1				
	□ ch r uts are t rued t □ a uacturer s ec ucat u uacturer s ec ucat u uacturer s				
	T□□ □□N⊡se □a□els are 815 □ □ a□□□e c□□crete □ad □□□19□				
	Cartrd es are le el a d the sa e he th t each a = 19 19 19 19 19 19 19 19 19 19 19 19 19				
	C_rrect Cartrd_e is claced iii each cac acd counting to incit cost stec				
	Cartrd e H d D a arac et s secure a d e a ed a fin N se Cartrd e				
	□□er□h□le a□d sl□t □□□ac□u□a□d M□□□ra□s a□ch□red □□□□22□2□□				
	□□□□ tra□s[t□□□□chec□ □□r □arr□□ s[de □a□els at □ac□u□ □□□23□				
	□□ch□r studɪs□are 38 □ □ □ax□□u□ a□□□e the □ad□□□□2□□				
	Da ☐hra ☐ s attached t ☐ the M ☐☐ra ☐ ☐u ☐des ☐☐25 ☐				
	Da_hra				
	□ach Fe⊡der □a⊡el has a te⊡s□□□ Die S□r□□□ □□□2□□				
	Mushr□□□ Washers la □ tat □□ sl □ts □□□2□□				
	M□□□ra⊞has □□d Ca□ attached □□□28□				
	N ⊑se Cartrd ⊑e s at the sa □ e he ⊞ht as □a □ Cartrd ⊑es □□□30 □				
	Fe⊡der □a□el □a□ ाs 20 □ □ □ mr Narr□□ s□ste□ s □□□33□				
	□ ts a d □uts are □r □ erl t □ t □ t □ t □ t □ t □ t □ t □ t □ t				
	S⊑ste□ is clear □□de□ris □ ith a□□ □ □□□ratitra□s□□rt □□ts □□□itted□				
	re 🗆 🗆 ed 📖 🖸 21 🗆				

## **Maintenance and Repair**

## **Inspection Frequency**

•	•
	፲r □uad□uard□ M10 are rec□□ □ e⊑ded as ⊑eeded ⊑ased u□□□ □⊒u□ e □⊑tra⊞c̄ a⊡d
□ □ act hst□r	□□□ sual Dr □e □□□ □s □ect □□s are rec □□ □ e □ded at least □□ce a □ □□th□Wal □□□ □
	re rec□□ □ e⊡ded at least □□ce a □ear□
Visual Dri	ve-By Inspection
1□ Chec	□t□see @there s e de ce ca ca cactossocer@r a calouc @scet@co
2□ Chec	



Warning: See Cartridice clace ect costructions concare 190

3□ □e sure the Steel N□se 呟 □□ □ace□
□□ N te the l cat □□ a □d c □□ d t □□ □ o the □uad □ uard □ M10 a □d the date □□ □ sual dr □□ □□ □

## Walk-Up Inspection Checklist

Cartrd □es □ ust □e re □aced □

Clear a d dis se
Clear a d re de excess de d t de ar de de the Manage de
□□ts are t⊞ht a□d rust ree□
□ ch r □ ts are securel a ch red □
D'a⊡hra⊡□ Le⊡s are stra⊞ht□
□ll Mushr□□□ Washer □sse□ □lēs are □r□□erl□seated□
Fe⊑der □a⊑els a⊑d Tra⊑st⊞□ □a⊑els sh⊑uld □est t⊞htl□a⊑a⊞st the s⊑ste□ □
Cartridies hale out leed dallaced and are orderloseated on their Sucourt oraclets.  To ensure outerded sheed characteristics cartrallocrushed Cartridies odue to loo sheed oracts outer outer of their Sucourt oraclets.
Male all lecessar relais as descriled a like See like in act listructions in a re
To deteron the main reduct should be replaced or is noted talloreusable a trained enomeer experienced to high on products and directed to the DoT out be consulted.

#### **Post-Impact Instructions**



Important: Trinity Highway makes no recommendation whether use or reuse of any part of the system is appropriate or acceptable following an impact. It is the sole responsibility of the project engineers to make that determination. It is critical that you inspect this product after assembly is complete to make certain that the instructions provided in this manual have been strictly followed.

1□ De□□□a□□r□trate tra⊞cc□□tr□ de□ces□
2□ □ sure all a ch c □ □ts ha e re □ a □ed □□ □ a ch red □ the r □ad □a □ sur ace □Re □ace a □□ □ □se □□ □□ □□ □ulled □ut a ch rs □
The performance of the system during an angle impact depends on a properly anchored Monorail.
3□ Clear a⊡d dīs⊡se □□a□□ de□rīs □□ sīte□
□□ □□sure the Mushr□□□ Washer □sse□ □□ēs are □□tact s□ the s□ste□ ca□ □e rest□red t□ t̄s □r□□□□al □□st□□□□
Caution:se e_ler_tect:::a_ddceshe retur_sh:::the Mushr:: Washer Die S:ssedDD_
5□ The D'a⊡hra□□ Su□□□rt Le⊡s are all □r□□erl□attached t□ the M□□□rat□
□□ Re□□□e the N□se □sse□□□ a□d attach a cha□□ t□ the □ull□ut □rac□ets □□ the □rst □□a□hra□□ □F□□ure 35□□□ttach □□th e□ds □□cha□□ t□ a hea□□ □eh□cle □such as a 1 t□□ □□c□u□□□□
^



Warning: Sta ☐d clear ☐ case cha ☐ ☐rea ☐s ☐r ☐ec ☐☐ es d ☐sc ☐☐☐ected ☐




Figure 35
Pullout Brackets



**Important:** Slocio cull the soste control to the c

□□ Re□ □□e all	crushed Cartr₫□es□
8□ □ll Dख⊡hra □ ust ⊡e re〔	□□s are □□ usa⊡e c□□dft□□□□Dfa⊡hra□□s □hlīch are □□□ed □r ha⊡e □e□t le⊡s ⊡aced□
	er □a⊑el ು □r□⊑erl□ attached □tth Mushr□□□ Washer □sse□ □tēs□Da□ a⊑ed l Tra⊡stt⊞□ □a⊑els □ ust ⊑e re⊡aced□
	Warning
	Anchor Torque and Clearance Requirements
	T □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □
	Fender Panel Critical Clearances
	Fe⊡der □a□el □a□ □20□ □
erla como 20 c c Imp the	oortant: □□sure the Mushr□□□ Washer □sse□ □lēs are t□r□ued t□ the e□d □ threads□□□the □a□s □et□ee□ the Fe□der □a□els are still t□□ lar□e□ti □ a□ □e essar□t□ re□lace □e□t □arts□
	UNDERLYING FENDER, TRANSITION, EXTENSION OR SIDE PANEL
	Figure 36 Fender Panel Gap
	crushed Cartr₫ es a d da a ed Cartr₫ e Su === t erac ets es e Cartr₫ e
	a□a⊡ed N⊡se ⊡sse□⊡⊡⊡ttach the ⊡e□ N⊡se t□ the шrst Dra⊡hra□□□See 32 a⊡d □8 ⊞r N⊡se attach□e⊡t ⊞struct⊞⊡s□
13 □ II □ □ts □ □	the s⊑ste□ are ade□uatel□t⊞ht□
1□□Site is iree	moo deorso
15⊡The □uad□	uard M10 s === read == use=

## Parts Ordering Procedure & Drawings

QuadGuard <sup>□</sup> M10 Ordering Information Chart						
Description:	Choices	Fill in this section				
Transition Panel Type?  Side DaDel aDd TraDstillD DaDel TDDes are DDDE DDDE DDDE DDDE DDDE DDDE DDDE DDD	<ul> <li>uad t W ea uardra </li> <li>uad t Thre ea uardra </li> <li>uad t Saet Shae arrer</li> <li>uad t Sme Slee arrer</li> <li>uad t erteal Cocrete</li> <li>d She</li> <li>Nce</li> </ul>					


### Parts List(s) & Quantities


		Tension Strut Backup	
PN	Description	6 Bay	3 Bay
10102902	⊞ect⊞□M⊡rtar 500เ2⊞□	3	2
1010230	□ac□u□□TS□2□□□□□M10□W□Decals	1	1
00 🗆 🗆 1	□		
10102508	□		
10103□□2	□□t□Hex□3ⅢX2□□8	2□	12
101031 🗆 2	□		
10102552	□	1	1
10102503	□	2□	12
10102213	□rac□et□□□□le□2X1□W⊞lles	2	2
10102211	□rac⊑et⊑Cart H⊡d D□□□□□□ M	1	1
10102212	□rac⊑et⊑Cart Su□□□rt□N□se□□ □ M	1	1
10102⊑00	□rac□et□Cartrাd□e Su□t□Dia□F□lded□□□	12	
10102□19	□rac⊑et□Cartr团□e□Su□t□TS □□□□□□	1	1
10102□11	□rac⊑et □□ull □□ ut □□ □	2	2
10102113	Dachra 🗆 🗆 🖸 🖸 🗆 🗆		3
10102313	□□dca□□M□□□raíi	1	1
10102 🗆 19	L⊡c⊡⊞□ □ar□Cartrাd □e Su□t□□□	1	1
1010253	M□□□rati □utde□□□	12	
10102311	M□□□raI□2 □a□s	1	1

		Tension Strut Backup	
PN	Description	6 Bay	3 Bay
10102312	M□□□rat⊡3 □a⊡s	1	0
10102202	N se L Narr	1	1
1010220 🗆	N©se©R©Narr©□□□□□□W1L□□□□	1	1
1010250 🗆	Nut⊡Hex Hea⊡⊡3⊞	2□	12
10102502	Nut⊡Hex Hea□□5®	13	
10102515	Nut⊡Hex⊡1 ⊞		
1010251 🗆	Nut⊑Hex⊏3ß		
10102501	Nut⊡Hex⊡Ra⊞5®	3□	22
10102002	□a□el□Fe□der□□□□	12	
1010200 🗆	□a □el □S īde □□ □	2	2
□2□53□	□ □e □3 □□ Schedule 80X3		
10102520	Scre □ □FL Hex S □c □et □5 ®X5	12	
1010290 🗆	Sh 🗆 🗆 12 🗆 🗆 X 3 5 🖪 X 8	12	
10102523	SrDe_1 1 D X 1 1 2	12	
101025 🗆	Stud	52	32
10102210	W SH R 10 = X2X1 SL TS	2	2
1010252	Washer□Flat□3เ8X1□□		
101025□8	Washer⊑Flat⊑3:8X2	2	2
10102500	Washer□Flat□5®X1 3⊞	12	
10102538	M20 Structual Flat Washer	52	32
10102528	Washer□L□c□□3□□	2□	12
10102530	Washer□L□c□□5®	1	1
1010253 🗆	Washer Mushr Fred	12	
10102539	M20 Structual Nut Hex Nut □al□	52	32





Warning: se selected here assessed assessed as sected here assessed as a sected here as a sected here assessed as a sected here assessed as a sected here as a sected here.






TS Concrete Pad 618686








**Tension Strut Backup** 





Monorail Assembly 625637














Safety Shape Barrier Transition QGMTSCVR-T4





**QGMTSCVR-ES** 

**Vertical Barrier Transition** 



**QGMTSCVR-SPE** Vertical Barrier Transition, Extended

### NOTES:



# www.ingalcivil.com.au sales@ingalcivil.com.au 1300 446 425



visit us on the web at www.trinityhighway.com. Materials and specifications are subject to change without notice. Please contact Trinity Highway to confirm that you are referring to the most current instructions.

www.trinityhighway.com