


# Ingal MPR

Motorcyclist Protection

Product Manual

MASH TL3 COMPLIANT

EN1317-8 COMPLIANT



www.ingalcivil.com.au



### Ingal MPR Motorcyclist Protection

#### 1.0 Introduction

The Ingal Motorcyclist Protection Rail (Ingal MPR) is a protective enhancement installed on existing four-wheel vehicle restraint systems to reduce the chances of serious injury to motorcyclists and pillion passengers in run-offroad accidents.

Traditional highway safety barriers installed on the road carriageways to restrain vehicles from impacting roadside hazards, these typically take the form of the W-Beam rail supported by a series of posts. These posts introduce a significant hazard to an errant motorcyclist in a run-offroad accident. The Ingal MPR consists of an under-riding rail which is mounted on a spring bracket. Upon impacting this rail, the spring bracket deflects back absorbing some of the impact energy from the motorcyclist, whilst the rail contains and re-directs the motorcyclist away from the rigid posts and hazards.



Ingal MPR Rail Length: 4m NLL 4m MPR Rail Mass: 12.3kg

Ingal MPR System Mass: 4.65kg per metre

Rail Height Above Ground: 60mm
Post Spacing: 2m or 5m
Ingal MPR Crash Test Impact Severity: **Level 1** 

The Ingal MPR rails and brackets are manufactured from hot-rolled steel flat products in accordance with AS/NZS1594. These items are hot dip galvanised in accordance with AS/NZS 4680 after fabrication leaving no surface untreated.

#### 3.0 Crash Test Analysis

Crash test guidelines provide a minimum set of requirements that a roadside barrier has to meet in order to demonstrate its satisfactory impact performance. Whilst crash test guidelines cannot include all possible impact conditions that may be experienced in the real world, the crash test matrix is selected to represent a "worst practical condition" for a roadside barrier impact. The Ingal MPR system has been fully crash tested and evaluated according to Standards UNE 135900-1 and 2 and UNE EN-1317-1 and 2, and has produced satisfactory results in the following full scale crash tests. **The dummy tests recorded an impact severity of Level 1 which is the lowest severity for this testing standard.** 

- TM1.6.0: Dummy to post, 60 km/h 30° angle of impact.
- TM.3.60: Dummy to point on barrier midway between posts, 60 km/h 30° angle of impact.

Ingal MPR has also been crash tested to MASH Test Level 3, this is the containment of a 2270kg utility and 1100kg car at 100 km/h.







Release 05/21 2

### Ingal MPR Motorcyclist Protection



### 4.0 Features and Benefits

- The specially designed anchoring system fully facilitates the positioning of the guard rail at the correct height, ensuring a uniform distance from the ground throughout the run and compensating for uneven terrain and height differences in the existing barriers. The mounting bracket also allows the motorcyclists rail to be raised to match alterations in the level of the road surface.
- The motorcyclist rail can be assembled and raised without the need to modify the traditional vehicle barrier system
- More space between the system and the ground (60mm), allowing water drainage, snow clearance, cleaning of hard shoulders, etc.
- The mounting bracket is symmetric, and is therefore the same for both the right and left side of the carriageway.
- Small number of components and ease of installation make the system very cost-effective.


#### 5.0 Installation

The specially designed anchoring system facilitates the positioning of the guard rail at the correct height, allowing deflection of the system when impacted.

Only items provided by Ingal are to be used for the installation of the Ingal MPR. The following written instructions are to be read in conjunction with Ingal's drawings. A generic Safe Work Method Statement is available upon request for installation operations.

#### 5.1 Site Preparation

This site should be prepared free of obstructing vegetation and other hazards that may interfere with the installation or operational performance of the system. Some sites may require minor grading if installed beyond the edge of the pavement shoulder.






Release 05/21



### Ingal MPR Motorcyclist Protection

### 5.2 Assembly

- Step 1 Assembly should be initiated with placing the post bracket around the guardrail posts, particular care should be taken to ensure the bracket is oriented in the correct direction with the open side facing the oncoming traffic for verge installations.
- Step 2 Attach the rail bracket to the post bracket with the M16 x 190 Hex Bolts. Typically the rail bracket will need to be abutting the underside of the block in the G4 guardrail system for convenient assembly. Tighten all fasteners to snug tight.
- Step 3 Mount the rail on the rail brackets with the appropriate fastener configuration. Before tightening, ensure a 60mm clearance between finished ground level and MPR rail.
- Step 4 Terminate beginning and end of run with MPR terminal piece.



The MPR rails can be field curved down to a radius of 26m. Rails can be machine curved down to a radius of 5m. Contact your local Ingal office for details.



### 6.0 Product Storage

All posts and rails are hot dip galvanized in accordance with AS/NZS 4680. It is important that stored galvanized work is stacked so that each item is well ventilated and can adequately drain rainwater from its surfaces.

Poor storage can give rise to wet storage stain (white rust) which is caused by water (rain or condensation) in badly drained or ventilated conditions. This can occur very quickly, particularly in warm, humid conditions.






















Release 05/21







SCALE

ISSUE FOR

DATE REV

DESCRIPTION

DRAWN

CHECKED APPROVED

DRAWING NUMBER

REFERENCE DRAWINGS

N.T.S. @

A3

INFORMATION ONLY

ICP-MPR-004

TYPE-B GUARDRAIL CONFIGURATION

ASSEMBLY DETAILS





### For more information

contact us on the web

## www.ingalcivil.com.au

### **Head Office: Sydney**

57-65 Airds Road, Minto, NSW 2566

Ph: +61 2 9827 3333 Fax: +61 2 9827 3300

Free call (within Australia):

1800 803 795

Email: sales@ingalcivil.com.au

### **Our Locations:**

- Adelaide Brisbane
- Melbourne Newcastle
- Perth Sydney Wagga
- Auckland Christchurch